

WAGO I/O System Field

1-Channel Analog Input; IO-Link Converter; 4 ... 20 mA;
2 × M12 connector

765-2701/200-000



Table of Contents


Provisions	5
1.1 Intended Use	5
1.2 Typographical Conventions	6
1.3 Legal Information	8
Safety	9
2.1 General Safety Regulations	9
2.2 Electrical Safety	9
2.3 Mechanical Safety	9
2.4 Indirect Safety	10
Overview	11
Properties	12
4.1 View	12
4.2 Indicators	13
4.2.1 Display	13
4.2.2 LEDs	13
4.3 Controls	14
4.4 Connections	15
4.4.1 IO-Link Side/Evaluation Side	15
4.4.2 Sensor Side	15
4.5 Dimensional Drawings	16
4.6 Circuit Diagram	17
4.7 Technical Data	18
Functions	19
5.1 Operating Modes	19
5.1.1 Stand-Alone Mode (without IO-Link)	19
5.1.2 IO-Link Mode	19
5.2 Operational Functions	19
5.2.1 "Output 1" Functions	19
5.2.2 "Output 2" Functions	20
5.3 Parameter Description	20
5.3.1 Product Menu Parameters	21
5.3.1.1 Main Menu Parameters	21
5.3.1.1.1 SP1/rP1 – Switching Point/Reverse Switching Point for OUT1 .	21
5.3.1.1.2 FH1/FL1 – Upper/Lower Switching Limiting Values for Window	
Function for OUT1	23
5.3.1.1.3 EF – Advanced Functions	23
5.3.1.2 Advanced Function Parameters	24
5.3.1.2.1 rES – Restore Default Settings	24
5.3.1.2.2 A.trm – Analog Termination for OUT2	24
5.3.1.2.3 ou1 – Output Function for OUT1	24

5.3.1.2.4	dS1/dr1 – Switching Delay/Reverse Switching Delay for OUT1	24
5.3.1.2.5	ScAL – Displayed Value Scaling	24
5.3.1.2.6	C.ASP/C.AEP – Customer-Specific Analog Starting Point/End-point	25
5.3.1.2.7	coLr – Display Colors and Color Change	26
5.3.1.2.8	cFH/cFL – Upper/Lower Value for Color Change	27
5.3.1.2.9	diS – Displayed Value Update Rate	28
5.3.1.2.10	Lo/Hi – Lower/Upper Input Measured Values	29
5.3.1.2.11	dAP – Damping	29
5.3.2	Parameters via IO-Link	29
5.3.2.1	C.uni – Customer-Specific Unit	29
5.3.2.2	S.Loc – Software Lock	29
5.3.2.3	Resetting [Hi] and [Lo] Memory	29
5.3.2.4	Default Command	29
5.3.2.5	Product Access Blocks	30
5.3.2.6	Manufacturer	30
5.3.2.7	Manufacturer Text	31
5.3.2.8	Product Name	31
5.3.2.9	Product ID	31
5.3.2.10	Product Text	32
5.3.2.11	Serial Number	32
5.3.2.12	Hardware Version	32
5.3.2.13	Firmware Version	32
5.3.2.14	Application-Specific Attribute	33
5.3.2.15	Device Access	33
5.4	Process Image	42
5.4.1	Input Process Data	42
5.4.2	Representation of the Current Value on the Input	43
	Planning	44
6.1	Structure Guidelines	44
6.1.1	Overcurrent Protection	44
6.1.2	EMC Installation	44
6.2	Behavior in the Event of a Communication Interruption	44
6.3	Aids	44
6.4	Connection Examples	45
	Installation and Removal	47
7.1	Mounting	47
7.1.1	Mounting the Product on a Mounting Clip	47
	Connection	48
8.1	Connecting the Plug	48
	Commissioning	49
9.1	Configuration and Parameterization	49
9.1.1	Parameterization Process – General	49
9.1.2	Locking/Unlocking the Product	49
9.1.3	Triggering the Timeout	50
9.1.4	Switching from the Main Menu to the Advanced Functions Menu	50
9.1.5	Entering Parameter Values/Numbers	50
9.1.6	[ou1] Programming Example – Output Function for OUT1	50

Operation	53
10.1 Operation via Buttons	53
Transport and Storage	54
Diagnostics	55
12.1 Diagnostics via Indicators	55
12.2 Diagnostics via IO-Link	55
12.2.1 Diagnostics	55
12.2.2 Detailed Diagnostics	56
12.2.3 Error Types	56
12.2.4 Events	56
Decommissioning	58
13.1 Disposal and Recycling	58
Service	59
14.1 Factory Settings	59
14.2 Application Example	60
14.3 Accessories	60
Appendix	61
15.1 Technical Data, Approvals, Guidelines and Standards	61
15.2 Installation Regulations Specified by Approvals	63
15.3 Protected Rights	63

Provisions

This document applies to the following product:

 **765-2701/200-000** (1AI FLD IOL CONV 4-20mA) 1-Channel Analog Input; IO-Link Converter; 4 ... 20 mA; 2 x M12 Connector

Product detail page	 www.wago.com/765-2701/200-000
---------------------	--

The product must only be installed and operated in accordance with the operating instructions. Knowledge of the operating instructions is required for proper use. You can find all documents and information on the detailed product page.

Additional document

-  [WAGO IO-Link Configurator](#)

1.1 Intended Use

The product 765-2701/200-000 is used to evaluate analog signals from connected sensors or other devices within a measuring range from 4 to 20 mA.


- The product is intended for indoor use.
- Operation of the product in other application areas is only permitted when corresponding approvals and labeling are present.

Improper Use

Improper use of the product is not permitted. The following cases in particular constitute improper use:

- Non-observance of the intended use
- Use without protective measures in an environment in which salt water, salt spray mist, icing, corrosive fumes, explosive gases, direct sunlight and ionizing radiation can occur
- Use of the product in areas with special risk that require continuous fault-free operation and in which failure of or operation of the product can result in an imminent risk to life, limb or health or cause serious damage to property or the environment (such as the operation of nuclear power plants, weapons systems, aircraft and motor vehicles)

Warranty and Liability

The provisions of the latest WAGO General Terms and Conditions of Deliveries and Services (GTC) apply as well as the Software License Terms for Standard Software (SW-License) applicable to software products and software embedded in WAGO hardware products, both available at:  www.wago.com.

In particular, the warranty is void if:

- The product is improperly used.
- The deficiency (hardware and software configurations) is due to special instructions.
- Modifications to the hardware or software have been made by the user or third parties that are not described in this documentation and that has contributed to the fault.

Individual agreements always have priority.

Obligations of Installers/Operators

The installers and operators bear responsibility for the safety of an installation or a system assembled with the product. The installer/operator is responsible for the proper installation and safety of the system. All laws, standards, guidelines, local regulations and accepted technology standards and practices applicable at the time of installation, and the instructions in the the products' Instructions for Use, must be complied with. In addition, the installment requirements for licensing must be observed. In the event of non-compliance, the product may not be operated within the scope of the approval.

1.2 Typographical Conventions





Number Notation

100	Decimals: Normal notation
0x64	Hexadecimals: C-notation
'100'	Binary: In single quotation marks
'0110.0100'	Nibbles separated by a period

Text Formatting

<i>italic</i>	Names of paths or files
bold	Menu items, entry or selection fields, emphasis
Code	Sections of program code
>	Selection of a menu point from a menu
"Value"	Value entries
[F5]	Identification of buttons or keys

Cross References / Links

	Cross references/links to a topic in a document
	Cross references / links to a separate document
	Cross references / links to a website
	Cross references / links to an email address

Sequence of Action

- ✓ This symbol identifies a precondition.
- 1. Action step
- 2. Action step
 - ⇒ This symbol identifies an intermediate result.
 - ⇒ This symbol identifies the result of an action.
- Individual action step

Lists

- Lists, first level
 - Lists, second level

Figures

Figures in this documentation are for better understanding and may differ from the actual product design.

Warning Messages

DANGER

Type and source of hazard

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

- Action step to reduce risk

WARNING

Type and source of hazard

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

- Action step to reduce risk

CAUTION

Type and source of hazard

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

- Action step to reduce risk

NOTICE

Type and source of malfunction (property damage only)

Indicates a potentially hazardous situation which, if not avoided, may result in damage to property.

- Action step to reduce risk

Information Notices

Note

Information


Indicates information, clarifications, recommendations, referrals, etc.

1.3 Legal Information

Intellectual property

The intellectual property of this document belongs to WAGO GmbH & Co. KG. The reproduction and distribution of its content (in whole or in part) is prohibited, unless otherwise provided by statutory provisions, written agreements or this document. In case of doubt, the written consent of WAGO GmbH & Co. KG must be obtained in advance.


Third-party products are always mentioned without any reference to patent rights. WAGO GmbH & Co. KG, or the manufacturer of third-party products, retains all rights regarding patent, utility model or design registration.

Third-party trademarks are referred to in the product documentation. The “®” and “™” symbols are omitted hereinafter. The trademarks are listed in the Appendix:  **Protected Rights [▶ 63]**.

Subject to Change

The instructions, guidelines, standards, etc., in this manual correspond to state of the art at the time the documentation was created and are not subject to updating service. The installer and operator bear sole responsibility to ensure they are complied with in their currently applicable form. WAGO GmbH & Co. KG retains the right to carry out technical changes and improvements of the products and the data, specifications and illustrations of this manual. All claims for change or improvement of products that have already been delivered – excepting change or improvement performed under guarantee agreement – are excluded.

Licenses

The products may contain open-source software. The requisite license information is saved in the products. This information is also available under:  www.wago.com.

Safety

2.1 General Safety Regulations

- This documentation is part of the product. Therefore, retain the documentation during the entire service life of the product. Pass on the documentation to any subsequent user of the product. In addition, ensure that any supplement to this documentation is included, if necessary.
- The product must only be installed and put into operation by qualified electrical specialists per EN 50110-1/-2 and IEC 60364.
- Comply with the laws, standards, guidelines, local regulations and accepted technology standards and practices applicable at the time of installation.

2.2 Electrical Safety

- Disconnect all power supplies from the product before performing any installation, repair or maintenance.
- Make sure the product does not carry any voltage before starting work.

Power Supply

- For non-hazardous active voltage per EN/UL/IEC 61010-1, SELV/PELV power supplies shall be used.
- Connecting impermissible current or frequency values may destroy the product.

Grounding/Protection/Fuses

- When handling the product, please ensure that environmental factors (personnel, work space and packaging) are properly equalized. Do not touch any conducting parts.
- Take suitable measures to protect against overload (e.g., a supply module with fuse or an external fuse).

Cables

- Always use connecting cables designed for the maximum current load.
- Additional heat can be produced at the clamping point by high currents and inherent heat generated by the product. Plan a higher temperature range for the conductors, or reduce inherent heat by selecting larger conductor cross-sections.
- The specified conductor cross-sections refer exclusively to the mechanical connection capacity of the clamping points. Always use connecting cables designed for the maximum current load.
- Use appropriate strain relief.

2.3 Mechanical Safety

- Before startup, please check the product for any damage that may have occurred during shipping. Do not put the product into operation in the event of mechanical damage.
- Do not open the product housing.

2.4 Indirect Safety

- Only use a dry or cloth or a clothed dampened with water to clean the product. Do not use cleaning agents, e.g., abrasive cleaners, alcohols or acetone.
- Only permit skilled personnel approved by WAGO to perform repair work.
- Replace any defective or damaged devices.
- Use only UL-approved category CYJV 2/7/8 cables to connect the product in UL-approved systems.
- Only use accessories authorized by WAGO.

Overview

The Analog/IO-Link Converter provides an economical, compact solution for easily incorporating conventional analog sensors and actuators into an IO-Link-capable system like the WAGO I/O System Field, depending on their type. This allows reliable, cost-effective, interference-immune acquisition and output of analog signals. Digital communication can easily be introduced (retrofitted) when old systems are modernized. The converter can be configured directly on the device via IO-Link. A compact design, IP67 protection and the high operating temperature range make the Analog/IO-Link Converter ideal for automation without control cabinets.

The product is used for evaluation of an analog signal, a connected sensor or another device with an analog output. The product has one analog current input and two outputs. Output 1 is digital, and output 2 can optionally be used as analog current output.

The product can be operated in stand-alone mode and IO-Link mode.

Properties

4.1 View




Figure 1: View

Table 1: Legend for Figure "View"

No.	Designation	
1	M12 A plug	IO-Link Side/Evaluation Side [▶ 15]
2	Tactile rings	Controls [▶ 14]
3	LEDs	LEDs [▶ 13]
4	Display	Display [▶ 13]
5	M12 A socket	Sensor Side [▶ 15]

4.2 Indicators

The product has a display for measured values and three LEDs to indicate the operating state.

4.2.1 Display



Figure 2: Indicators – Display

Table 2: Legend for Figure “Indicators – Display”

Color	Description
Red/green	<ul style="list-style-type: none"> 7-segment LED display 4-digit With color change

In operating mode, the display shows the input current value. The scaling of the current value depends on the ScAL parameter.

4.2.2 LEDs




Figure 3: Indicators – LEDs

Table 3: Legend for Figure “Indicators – LEDs”

No.	LED	Color
1	I OUT1	Yellow
2	POWER	Green
3	II -	-

4.3 Controls




Figure 4: Controls

Table 4: Legend for Figure “Controls”

No.	Button		Description
1	[esc]	Quit	<ul style="list-style-type: none"> Back to the previous menu Quit parameterization without saving the new value
2	[•]	Input	<ul style="list-style-type: none"> Open menu mode Select the parameter and confirm a parameter value
3	[▼]	Down	<ul style="list-style-type: none"> Select a parameter Set a parameter value (holding the button down changes the value continuously; a single button press changes it incrementally) Indicates the unit (press for one second in operating mode)
4	[▲]	Up	

4.4 Connections





Figure 5: Connections

Table 5: Legend for Figure "Connections"

No.	Designation	
1	IO-Link side (M12 A plug)	IO-Link Side/Evaluation Side [► 15]
2	Sensor side (M12 A socket)	Sensor Side [► 15]


4.4.1 IO-Link Side/Evaluation Side

Table 6: IO-Link Side/Evaluation Side (M12 A Plug)

Connection	Pin	Signal	Description
 M12 A plug, 4-pole	1	1L+	24 VDC power supply
	2	OUT2	Analog output
	3	1L-	0 V power supply
	4	OUT1	Digital Output (SIO)/C/Q IO-Link

4.4.2 Sensor Side

Table 7: Sensor Side (M12 A Socket)

Connection	Pin	Signal	Description
 M12 A socket, 5-pole	1	1L+	Sensor power supply
	2	AI 4 ... 20 mA	Analog input
	3	1L-	Sensor power supply
	4	-	Not assigned
	5	-	Not assigned

4.5 Dimensional Drawings




Figure 6: Dimensional Drawings

4.6 Circuit Diagram




Figure 7: Schematic Circuit Diagram

Table 8: Legend for Figure "Schematic Circuit Diagram"

No.	Designation
1	Analog input (I_{IN})
2	Digital Output SIO/IO-Link (OUT1)
3	Analog output $I_{OUT} = I_{IN}$ (OUT2)
4	Analog termination for OUT2 (A.trm)
5	Switchable internal load impedance
6	External load impedance (optional)

4.7 Technical Data

Note

Read technical data sheet!

You can find technical data on the product in the appendix under Technical Data, Approvals, Guidelines and Standards.

Table 9: Technical Data – Communication

Name	Value
Manufacturer ID	285 / 0x011D Bytes 01 29 / 0x01 0x1D
Product ID	8391309 / 0x800A8D Bytes 128 10 141 / 0x80 0x0A 0x8D
Manufacturer	WAGO GmbH & Co. KG
Manufacturer text	WAGO IO-Link Converter
Manufacturer URL	https://www.wago.com/765-2701/200-000
IO-Link revision	V1.1
Bit rate	COM2
Minimum cycle time	3.2 ms
SIO mode supported	Yes
Block parameterization	Yes
Data management	Yes

Functions

5.1 Operating Modes

The product supports the following operating modes:

-  **Stand-Alone Mode (without IO-Link) [▶ 19]**
-  **IO-Link Mode [▶ 19]**

5.1.1 Stand-Alone Mode (without IO-Link)

The product compares the measured current value with the parameter settings and switches the output according to the selected parameters. The measured value is shown on the alphanumeric display. The user can scale the displayed value (two-point scaling). This mode lacks IO-Link functionality. The parameters can be set either directly on the product itself or using an IO-Link tool, such as WAGO IO-Link Configurator.

5.1.2 IO-Link Mode

IO-Link is a communication system for connecting intelligent sensors and actuators to automation systems. IO-Link is governed by the IEC 61131-9 standard.


The product has an IO-Link communication interface that requires an IO-Link-capable module (IO-Link master) for interoperation.

The IO-Link interface allows direct access to the process data and diagnostic data and allows product parameters to be set during operation.

For more information about IO-Link and all the necessary information about the required IO-Link hardware and software, see www.wago.com/<item number>.

In IO-Link SIO mode, the product has the same functionality as in stand-alone mode. The measured value is also displayed.

IO Device Description (IODD)

The IODD (Input Output Device Description) required for configuration can be downloaded from the IO-Link community's website:  www.io-link.com.



5.2 Operational Functions

5.2.1 “Output 1” Functions

OUT1 (plug, pin 4):

- Digital output (state according to switching function setting)
- IO-Link interface

Selectable switching function:

- Hysteresis functions, make contact/break contact (see  **SP1/rP1 – Switching Point/Reverse Switching Point for OUT1 [▶ 21]**)
- Window functions, make contact/break contact (see  **FH1/FL1 – Upper/Lower Switching Limiting Values for Window Function for OUT1 [▶ 23]**)

OUT1 changes state when the input signal is above or below the switching limit settings. First switching point SP1 is set, then reset point rP1 (see [🔗 SP1/rP1 – Switching Point/Reverse Switching Point for OUT1 \[▶ 21\]](#)).

Note

Hysteresis change when rP1 parameter changes

The hysteresis defined in this way is retained even if SP1 is changed again. If the rP1 parameter is changed, the hysteresis also changes.

The width of the window is adjustable by the distance between FH1 and FL1.

- FH1 = upper value
- FL1 = lower value

5.2.2 “Output 2” Functions

OUT2 (plug, pin 2):

- Analog output (looping the analog input signal)

5.3 Parameter Description

Parameters are set through the ISDU mechanism (ISDU = Indexed Service Data Units) described in the IO-Link specification. This allows read and write access to the ISDU objects.

Regardless of the operating mode, there are two ways to parameterize the product:

- [🔗 Directly on the product via the integrated product menu \[▶ 21\]](#)
- [🔗 Via an IO-Link tool \[▶ 29\]](#)

Access via an IO-Link tool has a higher priority than parameterization via the product menu.

The ScAL scaling parameter only influences the display representation, not the transmitted process data or the actual switching threshold values.

Via IO-Link, the current value is always transmitted in μA . The switching thresholds can be set in 0.01 mA steps.

If a scaling is set, then the menu settings of the switching thresholds (SP, rP etc.) are also scaled. Via IO-Link, however, the settings continue to be displayed and executed in 0.01 mA steps (resolution: 14 bits).

If the product has been locked via IO-Link, then it can only be unlocked via the IO-Link interface.

Some parameters can only be set via the IO-Link interface.

The following parameters are available.

5.3.1 Product Menu Parameters




Figure 8: Product Menu Structure

Table 10: Legend for Figure "Product Menu Structure"

No.	Designation
1	Operating mode
2	Main menu
3	Advanced functions

5.3.1.1 Main Menu Parameters

5.3.1.1.1 SP1/rP1 – Switching Point/Reverse Switching Point for OUT1

Upper/lower limiting value for measured current at which OUT1 switches when hysteresis is set; only displayed when hysteresis function [Hno] or [Hnc] is set in [ou1].




Figure 9: SP1/rP1 – Switching Point/Reverse Switching Point for OUT1 – Hysteresis Functions

Table 11: Legend for Figure “SP1/rP1 – Switching Point/Reverse Switching Point for OUT1 – Hysteresis Functions”

Designation	Description
SP	Switching point
rP	Reverse switching point
HY	Hysteresis
Hno	Hysteresis function, make contact
Hnc	Hysteresis function, break contact

- Select [SP1] and set the value at which output OUT1 switches.
- Select [rP1] and set value at which output OUT1 switches back.

[rP1] is always less than [SP1]. Only values lower than the value for [SP1] can be entered.

[rP1] follows changes from [SP1] and maintains the hysteresis setting.

5.3.1.1.2 FH1/FL1 – Upper/Lower Switching Limiting Values for Window Function for OUT1

Upper/lower limiting value for measured current at which OUT1 switches within the window setting; the parameters are displayed only if window function [Fno] or [Fnc] has been set in [ou1].




Figure 10: FH1/FL1 – Upper/Lower Switching Limiting Values for Window Function for OUT1

Table 12: Legend for Figure “FH1/FL1 – Upper/Lower Switching Limiting Values for Window Function for OUT1”

Designation	Description
FH	Window, upper limiting value
FL	Window, lower limiting value
FE	Window
Fno	Window function, make contact
Fnc	Window function, break contact

- Select [FH1] and set upper limiting value.
- Select [FL1] and set lower limiting value.

[FL1] is always less than [FH1]. Only values lower than the value for [FH1] can be entered.

[FL1] follows changes from [FH1] and maintains the hysteresis setting.

5.3.1.1.3 EF – Advanced Functions

This parameter opens the advanced functions menu.

5.3.1.2 Advanced Function Parameters

5.3.1.2.1 rES – Restore Default Settings

This parameter resets all parameters to the factory settings.

1. Select [rES].
2. Press [●].
3. Press and hold down [▲] or [▼] until [----] appears.
4. Press [●] briefly.

5.3.1.2.2 A.trm – Analog Termination for OUT2

Note

Note the following for current measurement and evaluation:

If the internal analog termination is set to [On], output OUT2 must not be connected.

Table 13: A.trm – Analog Termination for OUT2

Parameters	Description
[OFF]	OUT2 is connected externally, e.g., to the analog input of another device.
[On]	OUT2 is not connected and the current path is terminated internally.

5.3.1.2.3 ou1 – Output Function for OUT1

Switching signal for the current limiting value

Table 14: ou1 – Output Function for OUT1

Parameters	Description
[Hno]	Hysteresis function/make contact
[Hnc]	Hysteresis function/break contact
[Fno]	Window function/make contact
[Fnc]	Window function/break contact

5.3.1.2.4 dS1/dr1 – Switching Delay/Reverse Switching Delay for OUT1

Table 15: dS1/dr1 – Switching Delay/Reverse Switching Delay for OUT1

Parameters	Description
Value 0.0 ... 50.0 s	Switching delay/reverse switching delay is enabled.
Value 0.0 s	Delay is disabled.

5.3.1.2.5 ScAL – Displayed Value Scaling

This setting acts as a multiplier for the parameters [C.ASP/C.AEP].

Table 16: ScAL – Displayed Value Scaling

Parameters	Description
[OFF]	The measured current value is not scaled.
[cccc]	Scaling without decimal place (×0001)
[ccc.c]	Scaling with one decimal place (×000.1)
[cc.cc]	Scaling with two decimal places (×00.01)

Parameters	Description
[c.ccc]	Scaling with three decimal places ($\times 0.001$)

5.3.1.2.6 C.ASP/C.AEP – Customer-Specific Analog Starting Point/Endpoint

Settings for scaled display values.

The parameters are only displayed if [ScAL] is set to [cccc], [ccc. c], [cc. cc] or [c. ccc].

- C.ASP value: -746 ... 9745 corresponds to 4 mA.
- C.AEP value: -366 ... 9366 corresponds to 20 mA.

If scaling is set via [ScAL], the C.AEP value must also be adjusted accordingly:

- For [ScAL] = [ccc.c] \rightarrow C.AEP value $\times 10$
- For [ScAL] = [cc.cc] \rightarrow C.AEP value $\times 100$
- For [ScAL] = [c.ccc] \rightarrow C.AEP value $\times 1000$

All displayed current values are interpolated on the basis of a two-point approximation ([SP1]+[rP1], [FH1]+[FL1], [cFH]+[cFL], [Lo]+[Hi]). IO-Link process data and parameters are not affected by the scaling.




Figure 11: C.ASP = min. value; C.AEP = max. value




Figure 12: C.ASP = max. value; C.AEP = min. value




Figure 13: C.ASP/C.AEP – Example with Scaled Display Value

Table 17: Example Menu Setting for Figure “C.ASP/C.AEP – Example with Scaled Display Value”

Example Menu Setting	
ScAL	ccc.c
C.ASP	0.0
C.AEP	100.0
Input	10 mA
Indicator	37.5

5.3.1.2.7 coLr – Display Colors and Color Change

Assignment of the display colors “red” and “green” within the measurement range.

Table 18: coLr – Display Colors and Color Change

Parameters	Description
[rEd]	Continuously red (independent of the measured value)
[GrEn]	Continuously green (independent of the measured value)
[r1ou]	Red when OUT1 switches
[G1ou]	Green when OUT1 switches
[r-cF]	Red when the measured value is between the [cFL] and [cFH] values
[G-cF]	Green when the measured value is between the [cFL] and [cFH] values




Figure 14: Hysteresis function with [r1ou]




Figure 15: Hysteresis function with [G1ou]




Figure 16: Window function with [r1ou]




Figure 17: Window function with [G1ou]

5.3.1.2.8 cFH/cFL – Upper/Lower Value for Color Change

If the [colr] parameters are set to [r-cF] or [G-cF], it is necessary to select the [cFH] parameter and set the corresponding upper limiting value, and also to select the [cFL] parameter and set the corresponding lower limiting value. The setting range corresponds to the measured values.

The lower setting value is the parameter [cFL].

The upper setting value is the parameter [cFH].




Figure 18: [r-cF] Function




Figure 19: [G-cF] Function

5.3.1.2.9 diS – Displayed Value Update Rate

Table 19: diS – Displayed Value Update Rate

Parameters	Description
[OFF]	In operating mode, the measured value display is switched off.
[d1]	Measured value update every 50 ms
[d2]	Measured value update every 200 ms
[d3]	Measured value update every 600 ms

Even with an unstable current value, [d1] provides optimal readability.

5.3.1.2.10 Lo/Hi – Lower/Upper Input Measured Values

Table 20: Lo/Hi – Lower/Upper Input Measured Values

Parameters	Description
[Lo]	Lower measured value
[Hi]	Upper measured value

Clear memory:

1. Select [Hi] or [Lo] parameter.
 2. Press and hold down [▲] or [▼] until [----] appears.
 3. Press [●] briefly.
- ⇒ Memory is cleared.

5.3.1.2.11 dAP – Damping

Damping of the analog measured value

The setting also affects the switching point, the IO-Link process data and the display.

Table 21: dAP – Damping

Parameters	Description
Value 0.000 ... 4.000 s	T value: 63 %
Value 0.000 s	Damping is disabled.

5.3.2 Parameters via IO-Link

The terms “index” and “subindex” used in the following tables refer to Indexed Service Data Units (ISDUs).

The following parameters are available.

You can find product diagnostic parameters in [🔗 Diagnostics via IO-Link \[▶ 55\]](#).

5.3.2.1 C.uni – Customer-Specific Unit

Customer-specific unit with max. 4 characters

5.3.2.2 S.Loc – Software Lock

Value: ON/OFF

The product is locked for local menu settings.

It can only be unlocked via IO-Link.

5.3.2.3 Resetting [Hi] and [Lo] Memory

Reset both memories: [Hi] and [Lo].

5.3.2.4 Default Command

Table 22: Variables – Default Command – General

Index	2
Access rights	Write-only

Table 23: Variables – Default Command

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Default command	-	Sub 0	UIntegerT	8 bits	-	(130) Restore factory default
						(161) Reset [Hi] and [Lo] memory
						(162) Reset [Lo] memory
						(163) Reset [Hi] memory
						(240) IO-Link 1.1 system test command 240, event 8DFE appears
						(241) IO-Link 1.1 system test command 241, event 8DFE disappears
						(242) IO-Link 1.1 system test command 242, event 8DFF appears
						(243) IO-Link 1.1 system test command 243, event 8DFF disappears
(255) Command with no effect – for internal use only						

5.3.2.5 Product Access Blocks

Table 24: Variables – Product Access Blocks – General

Index	12
Access rights	Read/write
Factor	-
Offset	-
Unit	-

Table 25: Variables – Product Access Blocks

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Product Access Blocks	-	Sub 0	RecordT	16 bits	-	-
Data management	-	bitOffs 1	BooleanT	1 bit	(false)	(false) open (true) locked
Local user interface	-	bitOffs 3	BooleanT	1 bit	(false)	(false) open (true) locked

5.3.2.6 Manufacturer

Table 26: Variables – Manufacturer Name – General

Index	16
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 27: Variables – Manufacturer Name

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Manufacturer	-	Sub 0	StringT	19 bytes	WAGO GmbH & Co. KG	-

5.3.2.7 Manufacturer Text

Table 28: Variables – Manufacturer Text – General

Index	17
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 29: Variables – Manufacturer Text

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Manufacturer text	-	Sub 0	StringT	11 bytes	WAGO IO-Link Converter	-

5.3.2.8 Product Name

Table 30: Variables – Product Name – General

Index	18
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 31: Variables – Product Name

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Product name	-	Sub 0	StringT	6 bytes	765-2701/0200 -0000 Con- verter	-

5.3.2.9 Product ID

Table 32: Variables – Product ID – General

Index	19
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 33: Variables – Product ID

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Product ID	-	Sub 0	StringT	6 bytes	0765-2701	-

5.3.2.10 Product Text

Table 34: Variables – Product Text – General

Index	20
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 35: Variables – Product Text

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Product Text	-	Sub 0	StringT	30 bytes	1AI FLD IOL CONV 4-20 mA	-

5.3.2.11 Serial Number

Table 36: Variables – Serial Number – General

Index	21
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 37: Variables – Serial Number

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Serial number	-	Sub 0	StringT	12 bytes	-	-

5.3.2.12 Hardware Version

Table 38: Variables – Hardware Version – General

Index	22
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 39: Variables – Hardware Version

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Hardware version	-	Sub 0	StringT	2 bytes	-	-

5.3.2.13 Firmware Version

Table 40: Variables – Firmware Version – General

Index	23
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 41: Variables – Firmware Version

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Firmware Version	-	Sub 0	StringT	5 bytes	-	-

5.3.2.14 Application-Specific Attribute

Table 42: Variables – Application-Specific Attribute – General

Index	24
Access rights	Read/write
Factor	-
Offset	-
Unit	-

Table 43: Variables – Application-Specific Attribute

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Application-Specific Attribute	-	Sub 0	StringT	32 bytes	***	-

5.3.2.15 Device Access

dAP

Table 44: Variables – dAP – General

Index	510
Access Rights	Read/write
Factor	0.001
Offset	0
Unit	s

Table 45: Variables – dAP

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
dAP	Damping of the measurement signal	Sub 0	UIntegerT	16 bits	60	0 ... 4000

BitCoded_ActiveEvents

Table 46: Variables – BitCoded_ActiveEvents – General

Index	545
Access Rights	Read-only
Factor	-
Offset	-
Unit	-

Table 47: Variables – BitCoded_ActiveEvents

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
BitCoded_ActiveEvents	Bit mask for currently pending events	Sub 0	RecordT	32 bits	-	-
Bit_31	Bit 31 indicates the assigned pending event.	bitOffs 31	BooleanT	1 bits	0	(0) noEv (1) 0x8DFF
Bit_30	Bit 30 indicates the assigned pending event.	bitOffs 30	BooleanT	1 bits	0	(0) noEv (1) 0x8DFE
Bit_10	Bit 10 indicates the assigned pending event.	bitOffs 10	BooleanT	1 bits	0	(0) noEv (1) 0x8CBA
Bit_9	Bit 9 indicates the assigned pending event.	bitOffs 9	BooleanT	1 bits	0	(0) noEv (1) 0x8C30
Bit_8	Bit 8 indicates the assigned pending event.	bitOffs 8	BooleanT	1 bits	0	(0) noEv (1) 0x8C10
Bit_1	Bit 1 indicates the assigned pending event.	bitOffs 1	BooleanT	1 bits	0	(0) noEv (1) 0x6320
Bit_0	Bit 0 indicates the assigned pending event.	bitOffs 0	BooleanT	1 bits	0	(0) noEv (1) 0x5000

ParaConfigFaultCollection

Table 48: Variables – ParaConfigFaultCollection – General

Index	546
Access Rights	Read-only
Factor	-
Offset	-
Unit	-

Table 49: Variables – ParaConfigFaultCollection

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
ParaConfig-FaultCollection	Indicates the parameter that was set incorrectly at the time of downloading.	Sub 0	-	-	0	-

Loc

Table 50: Variables – Loc – General

Index	550
Access Rights	Read/write
Factor	-
Offset	-
Unit	-

Table 51: Variables – Loc

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Loc	[Loc] locks sensor operation to protect against unintentional adjustment. It can be reset on the product.	Sub 0	UIntegerT	8 bits	1	(0) Loc (1) uLoc

diS

Table 52: Variables – diS – General

Index	552
Access Rights	Read/write
Factor	-
Offset	-
Unit	-

Table 53: Variables – diS

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
diS	Display settings	Sub 0	RecordT	16 bits	-	-
Display ON/OFF	-	bitOffs 7	BooleanT	1 bits	ON	(False) ON (True) OFF
Update rate	-	bitOffs 0	UIntegerT	6 bits	2	(1) d1 / fast (2) d2 / medium (4) d3 / slow

coLr

Table 54: Variables – coLr – General

Index	554
Access Rights	Read/write
Factor	-
Offset	-
Unit	-

Table 55: Variables – coLr

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
coLr	Assignment of display colors "red" and "green" within the measurement range	Sub 0	UIntegerT	8 bits	3	(2) rEd/display color red (independent of measured value) (3) GrEn/display color green (independent of measured value) (4) r1ou/display color red when OUT1 switches (5) G1ou/display color green when OUT1 switches

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
						(10) r-cF/display color red when the measured value is between the freely definable limiting values [cFL] and [cFH]
						(11) G-cF/display color green when the measured value is between the freely definable limiting values [cFL] and [cFH]

cFL

Table 56: Variables – cFL – General

Index	555
Access Rights	Read/write
Factor	0.001
Offset	0
Unit	mA

Table 57: Variables – cFL

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
cFL	Lower value for color change. This parameter is only active if a freely definable color window is selected in the coLr parameter: [r-cF] or [G-cF]. The setting range corresponds to the measurement range and is limited at the upper end by [cFH].	Sub 0	IntegerT	16 bits	4000	4000 ... 19900

cFH

Table 58: Variables – cFH – General

Index	556
Access Rights	Read/write
Factor	0.001
Offset	0
Unit	mA

Table 59: Variables – cFH

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
cFH	Upper value for color change; this parameter is only active if a freely definable color window is selected in the coLr parameter: [r-cF] or [G-cF]. The setting range corresponds to the measure range and is limited on the lower end by [cFL].	Sub 0	IntegerT	16 bits	20000	4100 ... 20000

Hi

Table 60: Variables – Hi – General

Index	560
Access Rights	Read-only
Factor	0.001
Offset	0
Unit	mA

Table 61: Variables – Hi

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Hi	Maximum value memory	Sub 0	IntegerT	16 bits	-	3600 ... 21000 (32764) no data (-32760) UL (32760) OL

Lo

Table 62: Variables – Lo – General

Index	561
Access Rights	Read-only
Factor	0.001
Offset	0
Unit	mA

Table 63: Variables – Lo

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Lo	Minimum value memory	Sub 0	IntegerT	16 bits	-	3600 ... 21000 (32764) no data (-32760) UL (32760) OL

ou1

Table 64: Variables – ou1 – General

Index	580
Access Rights	Read/write
Factor	-
Offset	-
Unit	-

Table 65: Variables – ou1

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
ou1	Output configuration [OUT1]	Sub 0	UIntegerT	8 bits	3	(3) Hno/hysteresis function, make contact (4) Hnc/hysteresis function, break contact (5) Fno/window function, make contact (6) Fnc/window function, break contact

dS1

Table 66: Variables – dS1 – General

Index	581
Access Rights	Read/write
Factor	0.1
Offset	0
Unit	s

Table 67: Variables – dS1

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
dS1	Switching delay for [OUT1]	Sub 0	UIntegerT	16 bits	0	0 ... 500

dr1

Table 68: Variables – dS1 – General

Index	582
Access Rights	Read/write
Factor	0.1
Offset	0
Unit	s

Table 69: Variables – dS1

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
dS1	Reverse switching delay for [OUT1]	Sub 0	UIntegerT	16 bits	0	0 ... 500

SP_FH1

Table 70: Variables – SP_FH1 – General

Index	583
Access Rights	Read/write
Factor	0.001
Offset	0
Unit	mA

Table 71: Variables – SP_FH1

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
SP_FH1	Switching point 1; [SP1] must be greater than [rP1]. Take the current [rP1] value into account. If [SP1] is set below [rP1], this is rejected. [SP] = [FH] and [rP] = [FL] for [OU1] = Fno, Fnc	Sub 0	IntegerT	16 bits	6000	4100 ... 20000

rP_FL1

Table 72: Variables – rP_FL1 – General

Index	584
Access Rights	Read/write
Factor	0.001
Offset	0
Unit	mA

Table 73: Variables – rP_FL1

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
rP_FL1	Reverse switching point 1; [rP1] must be less than [SP1]. Take the current [SP1] value into account. If [rP1] is set below [SP1], this is rejected. [rP] = [FL] and [SP] = [FH] for [OU1] = Fno, Fnc	Sub 0	IntegerT	16 bits	5000	4000 ... 19900

ScAL

Table 74: Variables – ScAL – General

Index	900
--------------	-----

Access Rights	Read/write
Factor	-
Offset	-
Unit	-

Table 75: Variables – ScAL

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
ScAL	Decimal place setting	Sub 0	UIntegerT	8 bits	0	(0) OFF (1) cccc (2) ccc.c (3) cc.cc (4) c.ccc

A.Trm

Table 76: Variables – A.Trm – General

Index	901
Access Rights	Read/write
Factor	-
Offset	-
Unit	-

Table 77: Variables – A.Trm

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
A.Trm	Activation of the internal termination of the measuring circuit. If OUT2 is not connected, then this internal terminating resistor must be switched on.	Sub 0	UIntegerT	8 bits	1	(0) OFF (1) ON

C.ASP

Table 78: Variables – C.ASP – General

Index	910
Access Rights	Read/write
Factor	1
Offset	0
Unit	-

Table 79: Variables – C.ASP

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
C.ASP	Customer-specific starting point; this value is assigned to the lower value of the analog input. This parameter is active only when ScAL is set to [ON].	Sub 0	IntegerT	16 bits	400	-746 ... 9745

C.AEP

Table 80: Variables – C.AEP – General

Index	911
Access Rights	Read/write
Factor	1
Offset	0
Unit	-

Table 81: Variables – C.AEP

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
C.AEP	Customer-specific endpoint; this value is assigned to the upper value of the analog input. This parameter is active only when ScAL is set to [ON].	Sub 0	IntegerT	16 bits	2000	-366 ... 9366

C.uni

Table 82: Variables – C.uni – General

Index	922
Access Rights	Read/write
Factor	-
Offset	-
Unit	-

Table 83: Variables – C.uni

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
C.uni	Customer-specific unit with max. 4 characters This function is only available via IO-Link.	Sub 0	StringT	4 bits	mA	-

5.4 Process Image

Note

Process data is shown from the product’s perspective!

The following process data is presented from the product’s perspective. Some controllers swap the high and low byte when addressing byte by byte.




Figure 20: Input Process Data

5.4.1 Input Process Data

Table 84: Input Process Data

Byte	Data Type (Bits)	Bit Offset	Content	Value Range	Description	Factor	Unit
0	IntegerT (16)	0	Current value	-32760	Underrange	0.001	mA
				3600 ... 21000	3.6 ... 21.0 mA		
				32760	Overrange		
				32764	No data		
2	BooleanT (1)	0	Status of OUT1	0	Inactive	0.001	mA
				1	Enabled		
2	(7)	1	Reserved	-	-	-	-
2	(8)	8	Scaling	-	-	-	-

You can find an example calculation for the scaling in [Application Example \[▶ 60\]](#).

5.4.2 Representation of the Current Value on the Input





Figure 21: Display – Analog Value Representation

Table 85: Legend for Figure "Display – Analog Value Representation"

No.	Description
1	No measurement data
2	Input current outside range (-)
3	Input current outside range (+)
4	Displayed message or value. The input current is not represented in scaled form here.
nPrb	No sensor
UL	Process value too low
OL	Process value too high
	Hysteresis range

Planning

6.1 Structure Guidelines

6.1.1 Overcurrent Protection

Protecting the Power Supply

Use a fuse to protect the supply voltage.

Table 86: Protecting the Power Supply

Potential	M12 Plug	Fuse
1L+ / power supply	Pin 1	≤2 A, slow
C/Q IO-Link (if not fused via IO-Link master)	Pin 4	≤2 A

Required trip characteristics of the fuses: $T_{fuse} \leq 120$ s at max. 6.25 A (fire protection)

Alternatively, the product can be powered by a limited-energy circuit per IEC 61010-1 or Class 2 per UL 1310.

The current loop of the analog input must be terminated. Only one load impedance may be connected – either an internal or an external one (see [🔗 A.trm – Analog Termination for OUT2 \[▶ 24\]](#)).

6.1.2 EMC Installation

- **Keep data and signal lines separate from interference sources.**
Route data and signal lines separately from all power supply cables and other sources of high electromagnetic emissions (e.g., frequency converters or drives).
- **Observe maximum cable lengths**
The maximum lengths of the connecting cables are as follows:
 - Without IO-Link communication on each connection side of the product: 30 m
 - With IO-Link communication on the product master side: 20 m

6.2 Behavior in the Event of a Communication Interruption

In case of communication interruption, the transmitted values are delivered to ZERO.

6.3 Aids

Depending on the operating mode, parameters can be set either directly on the product via a menu, via the PLC or with an IO-Link tool like WAGO IO-Link Configurator.

i Note

Take parameterization differences into account

Parameterization via IO-Link tools or a PLC deviates in some points from parameterization via the product menu.

You can obtain the WAGO IO-Link Configurator software, as well as the associated product manual with a detailed description of the software, from www.wago.com.

6.4 Connection Examples




Figure 22: Connection Example without IO-Link Master

Table 87: Legend for Figure "Connection Example without IO-Link Master"

No.	Description
1	Sensor with analog output (e.g., pressure sensor)
2	Measured value/limiting value display
3	Digital output
4	Looping the analog signal
5	Switching amplifier
6	Relay output for switching electric motors, valves etc.




Figure 23: Connection Example with IO-Link Master

Table 88: Legend for Figure "Connection Example with IO-Link Master"

No.	Description
1	Sensor with analog output (e.g., pressure sensor)
2	WAGO Analog IO-Link Converter
3	Complete bidirectional IO-Link communication <ul style="list-style-type: none"> • Remote display: Read and display measured current. • Remote parameterization: Read and change parameter setting.
4	Looping the analog signal
5	IO-Link master
6	Fieldbus (Profinet, EtherCAT, EtherNet/IP etc.)
7	PLC

Installation and Removal

7.1 Mounting

7.1.1 Mounting the Product on a Mounting Clip

The product can be secured with a Mounting Clip.




Figure 24: Mounting Clip (Secured with an M4 Screw or Cable Tie)




Figure 25: Mounting Clip with Product Attached

The Mounting Clip is not included upon delivery. You can find more information in [🔗 Accessories \[▶ 60\]](#).

Connection

8.1 Connecting the Plug

The mounting method must not cause mechanical stress on the M12 connection parts. Depending on the conditions of use, it may also be necessary to protect the product against mechanical stresses (shock/vibration) through appropriate mounting.

✓ The circuit must be protected by the use of a fuse or powered by a limited-energy circuit.

1. Connect the pluggable connectors of the connecting cables to the product.
2. Tighten the cap nut with a tightening torque of at least 1.0 Nm.

Once the power supply is applied, the product is in the operating mode. It performs its measurement and evaluation functions and provides output signals according to the parameter settings (see [🔗 Parameter Description \[p. 20\]](#)).

Commissioning

9.1 Configuration and Parameterization

Note

The product is in operating mode during parameterization

During the parameterization process, the product remains in operating mode. It continues to perform its monitoring functions with the existing parameters until the parameterization is completed.

9.1.1 Parameterization Process – General

Every parameterization process involves six steps. The basic procedure for a parameterization process is described below.

1. Use the **[•]** button to switch from operating mode to parameterization mode.
2. Select the desired parameter – [SP1], [rP1] etc. – with the **[▼]** or **[▲]** button.
3. Select the parameter's programming mode with the **•** button.
4. Select or modify the parameter value with the **[▼]** or **[▲]** button > 2 s.
5. Use the **[•]** button to confirm the parameter value setting.
6. Return to operating mode with the **[esc]** button.

9.1.2 Locking/Unlocking the Product

To prevent incorrect entries, the product can be locked electronically. Parameter values and other settings can be displayed but not modified.

When delivered, the product is unlocked.

Locking

- ✓ Make sure that the product is in normal operating mode.
- Hold the **[esc]** and **[▲]** buttons down at the same time for 10 s.
 - ⇒ **[Loc]** appears on the display.
 - ⇒ The product is locked.

When it is in the locked state, the product always shows **[Loc]** on the display if an attempt is made to change parameter values.

Unlocking

- Hold the **[esc]** and **[▲]** buttons down at the same time for 10 s.
 - ⇒ **[uLoc]** appears on the display.
 - ⇒ The product is unlocked.

Note**Customer-side locking**

If [C.Loc] is displayed when attempt is made to change a parameter value, IO-Link communication is active (temporary locking).

Note**Software locking**

If [S.Loc] is displayed, the sensor is permanently locked by software. This locking can only be removed by IO-Link parameterization software.

9.1.3 Triggering the Timeout

If no button is pressed for 30 s during the parameter setting process, the product returns to operating mode and the value remains unchanged.

9.1.4 Switching from the Main Menu to the Advanced Functions Menu

1. Press the [●] button to switch to the menu.
2. Press the [▼] or [▲] button until [EF] appears on the display.
3. Press the [●] button to confirm.
 - ⇒ The first parameter of the advanced function menu is displayed ([rES]).
 - ⇒ You are now in the advanced functions menu.

9.1.5 Entering Parameter Values/Numbers

1. Press the [▼] or [▲] button for at least 2 s.
2. Holding the button down changes the value continuously; a single button press changes it incrementally.
 - ⇒ [▼] reduces the value and [▲] increases it incrementally.
3. Press the [●] button briefly to confirm the value setting.
 - ⇒ The new value is saved.
 - ⇒ The parameter value is now set.

9.1.6 [ou1] Programming Example – Output Function for OUT1**(1) Switch from operating mode to parameterization mode**

- Press the [●] button to switch to the menu.
 - ⇒ The first parameter of the menu appears: [SP1].

SP 1

(2) Select the relevant parameter (here: [ou1])

1. Press the [▼] button until the [EF] parameter appears on the display.

EF

2. Press the [●] button to switch to the advanced function menu.

⇒ The first parameter of the advanced function menu appears: [rES].

rES

3. Press the [▼] button until the relevant parameter, [ou1], appears on the display.

ou1

(3) Switch to the parameter's programming mode

- Press the [●] button to switch to programming mode.

⇒ The parameter that is currently being set appears: [Hno].

Hno

(4) Select or modify the parameter (for example, in this case: [Fnc])

1. Press the [▼] button for at least 2 s.

⇒ The parameter that is currently being set flashes: [Hno].

Hno

⇒ After 2 s, the value can be changed.

2. Holding the button down changes the value continuously; a single button press changes it incrementally.

Fnc

You can find more information on entering numbers in [🔗 Entering Parameter Values/Numbers \[▶ 50\]](#).

(5) Confirm the parameter value setting

1. Press the [●] button briefly.

⇒ The parameter appears again.

⇒ The new setting value is saved.

ou1

2. To set more parameters, press the [▼] or [▲] button until the relevant parameter appears.

(6) Return to operating mode

1. Press the [esc] button.

2. Press the [▼] or [▲] button until the current measured value appears, or wait 30 s for the timeout function. The display then automatically switches back to the display of the current measured value.

⇒ The current measured value is displayed.

12.34

⇒ The product is back in operating mode.

Operation

10.1 Operation via Buttons

The product has two tactile rings with a total of four buttons on them. Each button can be pressed separately. To execute a command, press the corresponding corner of one of the two tactile rings: [esc], [●], [▼] or [▲].

- Press one of the buttons to move through the product menu and parameterize the product.
 - ⇒ The functions and meanings of the buttons can be found in [🔗 Controls \[▶ 14\]](#).




Figure 26: Pushing a Button

⇒ Depending on button selected, the corresponding result appears in the display.

i Note

Do not place product on mounting surfaces while pressing tactile ring

To ensure correct operation of the tactile rings (buttons), do not attach or place the product directly on a mounting surface. For installation, use the 765-101/000-000 Mounting Clip (see [🔗 Accessories \[▶ 60\]](#)).

Transport and Storage

The original packaging offers optimal protection during transport and storage.

- Store the product in suitable packaging, preferably the original packaging.
- Only transport the product in suitable containers/packaging.
- Make sure the product contacts are not contaminated or damaged during packing or unpacking.
- Observe the specified ambient climatic conditions for transport and storage.

Diagnostics

12.1 Diagnostics via Indicators

Table 89: Diagnostics via Indicators – LEDs

LED	LED State	Explanation
I	On	Output 1 is switched.
POWER	On	The power supply is OK. The product is in operating mode.
	Off	The product in programming mode.
II	-	No function

Table 90: Diagnostics via Indicators – Display

Display Status	LED State I	LED State Power	Explanation
OFF	Off	Off	The supply voltage is too low
SC1	Flashing	Any	Overcurrent at the OUT1 switching output.
C.Loc	Any	Any	Parameterization via buttons is locked due to active IO-Link transmission.
S.Loc	Any	Any	Parameterization via buttons has been disabled by the software.
Loc	Any	Any	Parameterization via buttons is disabled.
OL	Any	On	The process value is too high (measured current > 21 mA).
UL	Any	On	The process value is too low (measured current < 3.6 mA).
nPrb	Any	On	No sensor is connected to the analog input.

12.2 Diagnostics via IO-Link

12.2.1 Diagnostics

Table 91: Variables – Diagnostics – General

Index	36
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 92: Variables – Diagnostics

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range
Device status	-	Sub 0	UIntegerT	8 bits	0	(0) Product is OK
						(1) Maintenance required
						(2) Outside specification
						(3) Function test
						(4) Error
						5 ... 255 (reserved)

12.2.2 Detailed Diagnostics

Table 93: Variables – Detailed Diagnostics – General

Index	37
Access rights	Read-only
Factor	-
Offset	-
Unit	-

Table 94: Variables – Detailed Diagnostics

Name	Description	Subindex	Data Type	Length	Factory Setting	Value Range [h]
Detailed device status	-	Sub 0	-	21 bytes	00 00 00	-

12.2.3 Error Types

Table 95: Process Image – Error Types

Error Code	Name	Description
32768 d / 0x8000	Application error in product – no details	Access was denied by the product. No detailed information is available.
32785 d / 0x8011	Index does not exist	Access to an index that does not exist
32786 d / 0x8012	Subindex does not exist	Access to a subindex that does not exist
32800 d / 0x8020	Service is currently unavailable	The parameter cannot be accessed. The product does not allow this in its current state.
32803 d / 0x8023	Access denied	Write access to a read-only parameter
32816 d / 0x8030	Parameter value outside valid range	The parameter value that was written is outside the permissible value range.
32819 d / 0x8033	Parameter too long	The length of the parameter that was written is greater than is allowed.
32820 d / 0x8034	Parameter too short	The length of the parameter that was written is less than is allowed.
32821 d / 0x8035	Function unavailable	The product does not support the command that was written
32822 d / 0x8036	Function currently unavailable	The product does not support the command that was written in the current state.
32832 d / 0x8040	Invalid parameter set	The individual parameter value that was written collides with the other parameter settings.
32833 d / 0x8041	Inconsistent parameter set	Inconsistencies were detected at the end of the block parameter transfer. The product plausibility check failed.
32898 d / 0x8082	Application not ready	Access was denied because the product is not currently ready.

12.2.4 Events


Table 96: Process Image – Events

Code	Device status	Type	Description
20480 d / 0x5000	Hardware fault in product	Error	Replace the product.
25376 d / 0x6320	Parameter error	Error	Check the datasheet and values.

Code	Device status	Type	Description
35856 d / 0x8C10	Process value above valid range	Warning	Process value uncertain. Note: This event will not be transferred on the event channel. It can only be read out via index 37 (detailed diagnostics) or 545 (Bit-Coded_ActiveEvents).
35888 d / 0x8C30	Process value below valid range	Warning	Process value uncertain. WARNING! This event is not transferred on the event channel. It can only be read out via index 37 (detailed diagnostics) or 545 (Bit-Coded_ActiveEvents).
36026 d / 0x8CBA	Probe fell off	Error	Fix problem.
36350 d / 0x8DFE	Test event 1	Warning	Event appears when index 2 is set to a value of 240; event disappears when index 2 is set to a value of 241.
36351 d / 0x8DFF	Test event 2	Warning	Event appears when index 2 is set to a value of 242; event disappears when index 2 is set to a value of 243.

Decommissioning

13.1 Disposal and Recycling



WEEE Mark

Electrical and electronic equipment may not be disposed of with household waste. This also applies to products without this mark.

Electrical and electronic equipment contain materials and substances that can be harmful to the environment and health. Electrical and electronic equipment must be disposed of properly after use. Environmentally friendly disposal benefits health, protects the environment from harmful substances in electrical and electronic equipment and enables sustainable and efficient use of resources.

- Observe the national and local regulations for the disposal of electrical and electronic equipment, lithium-ion batteries, lead–acid batteries and packaging.
- Clear any data stored on electrical and electronic equipment.
- Remove lithium-ion batteries, lead–acid batteries or memory cards that are added to the electrical and electronic equipment.
- Wear appropriate personal protective equipment when removing the lithium-ion batteries/lead–acid batteries.
- Dispose of the removed lithium-ion batteries/lead–acid batteries according to your local waste regulations (e. g. collection boxes at the retail or local collection points).
- Have electrical and electronic equipment sent to a local collection point.
- Dispose of all types of packaging to ensure a high level of recovery, reuse and recycling.
- Transport packages from the B2B area can be taken back free of charge via a return system in accordance with the Packaging Act. Please contact our service provider Interseroh directly. The corresponding certificate can be found at: [🌐 corporate-certificates](#)
- Throughout Europe, Directives 2006/66/EC, 94/62/EC and 2012/19/EU (WEEE) apply. National directives and laws may differ.

Service

14.1 Factory Settings

Table 97: Factory Settings

Parameters		Factory Settings	Possible Settings
SP1/FH1	Switching point for OUT1	6.00	-
rP1/FL1	Reverse switching point for OUT1	5.00	-
A.trm	Analog termination for OUT2	ON	ON OFF
ou1	Output function for OUT1	Hno	Hno Hnc Fno Fnc
dS1	Switching delay for OUT1	0.0 s	-
dr1	Reverse switching delay for OUT1	0.0 s	-
ScAL	Scaling value	OFF	OFF cccc ccc.c cc.cc c.ccc
C.ASP	Customer-specific analog starting point	-	-
C.AEP	Customer-specific analog endpoint	-	-
C.uni*	Customer-specific unit	mA	-
coLr	Color display	GrEn	rEd GrEn r1ou G1ou r-cF G-cF
cFH	Color change, upper limiting value	20.00	-
cFL	Color change, lower limiting value	4.00	-
diS	Display update rate	d2 (200 ms)	OFF d1 (50 ms) d2 (200 ms) d3 (600 ms)
Lo	Lower input measured value	-	-
Hi	Upper input measured value	-	-
dAP	Analog measured value damping	0.060 s (= 60 ms)	-

* Only configurable via IO-Link and parameterization software

14.2 Application Example

Scaling Example

- ✓ 0xFD corresponds to -3 as a signed integer value
 - Multiply the measured value by 10^{-3} (= to the power of the desired scaling value).
- ⇒ As a result, you get the value in mA.

14.3 Accessories

Table 98: Accessories

Item No.	Product
765-101/000-000	Mounting Clip

Appendix


15.1 Technical Data, Approvals, Guidelines and Standards

Note

Subject to changes!

Please also observe the further product documentation! You can generate the current datasheet at any time at: www.wago.com /<item number>.


See also

 Data_sheet_765-2701/200-000 [▶ 62]

15.1.1 Data_sheet_765-2701/200-000

765-2701/200-000

1-Channel Analog Input; IO-Link Converter; 4 ... 20 mA; 2 x M12 Connection



Application:
 Decentralized display, preprocessing and conversion of analog signals.
 The device is used for signal acquisition of a connected sensor or another device with an analog output (4 ... 20 mA).
 The device has an analog current input and a display with controls for status indication and parameterization.

Use as an IO-Link device:
 The device has an IO-Link communication interface that requires an IO-Link-capable module (IO-Link master) for interoperation.
 The IO-Link interface allows direct access to the process and diagnostic data and enables setting of the device parameters during operation.

Use as a stand-alone device without IO-Link:
 The device compares the measured current value with the set parameters and switches the output according to the selected function.
 This mode is without IO-Link functionality. Parameterization is performed either via the push ring or with the WAGO IO-Link Configurator.

Description	Item No.	PU
1AI FLD IOL CONV 4-20mA	765-2701/200-000	1
Accessories		
Mounting clip	765-101/000-000	1
IO Device Description (IODD)	Download: www.wago.com	
Approvals/Tests		
Conformity marking	CE	
UL listed	Pending	
IO-Link		
MTTF	373 years	
Technical Data		
Ambient temperature (operation)	-25 ... 60 °C (70 °C with display switched off)	
Ambient temperature (storage)	-25 ... +70 °C	
Relative humidity (without condensation)	max. 90 % (31 °C); linearly decreasing to 50 % (40 °C)	
Operating altitude	0 ... 2000 m	
Protection type	IP67	
Pollution degree	3	
Weight	108 g	
Dimensions	63 x 30 x 24 mm	
Housing material	PA	
Indicators	Digital output: 1 x LED yellow; Power: 1 x LED green; Display: 7-segment LED, red/green	
Length of connection cables	30 m without IO-Link on each side 20 m with IO-Link on the master side	

Technical Data	
Supply voltage	24 VDC; -25 ... +25 %; (18 ... 30 VDC)
Power consumption	1 W
Operating modes	SIO; IO-Link
Inputs	
Number of analog inputs	1
Connection technology	M12-A socket; 5-pole
Signal type (current)	4 ... 20 mA
Sensor supply	24 VDC
Sensor current	≤ 800 mA
Precision	0.5 % of the upper-range value
Outputs	
Digital output (OUT 1)	
Number of digital outputs	1
Connection technology	M12-A plug; 4-pole
Current carrying capacity per output	50 mA
Signal type (voltage)	10 ... 30 VDC
Output circuit design	Make/break contact; parameterizable
Analog output (OUT 2)	
Number of analog outputs	1
Signal type (current)	4 ... 20 mA
Precision	0.5 % of the upper-range value
Resolution	10 bits
IO-Link	
Communication interface	IO-Link Class A
Transmission type	COM2 (38.4 kBaud)
IO-Link revision	1.1
Process data	1 x 16-bit IN (analog)
Process cycle time (min.)	3.2 ms
Parameters via IO-Link	Operating mode, switching point, delay, scaling, etc.

WAGO GmbH & Co. KG
 Subject to changes

19.07.23

Postfach 2880 - D-32385 Minden
 Hansastr. 27 - D-32423 Minden

Phone: +49(0)571/887-0
 Fax: +49(0)571/887-844169

Email: info@wago.com
www.wago.com

15.2 Installation Regulations Specified by Approvals

For the Scope of cULus:

Electricity can only be supplied by via SELV/PELV circuits. Device powered according to “Limited Energy” per UL 61010-1, chapter 9.4. External circuits must be isolated per UL 61010-2-201, figure 102.

The device is safe at least under the following conditions:

- Indoor use
- Altitude up to 2000 m
- Maximum relative humidity of 90 %, non-condensing
- Pollution degree 3
- Use UL-certified category CYJV 2/7/8 connection cables with suitable data to connect the device to the IO-Link devices.
- No evaluation of the IP class has been performed by UL.
- No special treatment is required when cleaning the device.

15.3 Protected Rights

- Adobe® and Acrobat® are registered trademarks of Adobe Systems Inc.
- Android™ is a trademark of Google LLC.
- Apple, the Apple logo, iPhone, iPad and iPod touch are registered trademarks of Apple Inc. registered in the USA and other countries. “App Store” is a service mark of Apple Inc.
- AS-Interface® is a registered trademark of the AS-International Association e.V.
- BACnet® is a registered trademark of the American Society of Heating, Refrigerating and Air Conditioning Engineers, Inc. (ASHRAE).
- *Bluetooth*® is a registered trademark of Bluetooth SIG, Inc.
- CiA® and CANopen® are registered trademarks of CAN in AUTOMATION – International Users and Manufacturers Group e.V.
- CODESYS is a registered trademark of CODESYS Development GmbH.
- DALI is a registered trademark of the Digital Illumination Interface Alliance (DiiA).
- Docker and the Docker logo are trademarks or registered trademarks of Docker, Inc. in the United States and/or other countries. Docker, Inc. and other parties may also have trademark rights in other terms used herein.
- EtherCAT® is a registered trademark and patented technology licensed by Beckhoff Automation GmbH, Germany.
- ETHERNET/IP™ is a registered trademark of the Open DeviceNet Vendor Association, Inc (ODVA).
- EnOcean® is a registered trademark of EnOcean GmbH.
- Google Play™ is a registered trademark of Google Inc.
- IO-Link is a registered trademark of PROFIBUS Nutzerorganisation e.V.
- KNX® is a registered trademark of the KNX Association cvba.
- Linux® is a registered trademark of Linus Torvalds.
- LON® is a registered trademark of the Echelon Corporation.
- Modbus® is a registered trademark of Schneider Electric, licensed for Modbus Organization, Inc.
- OPC UA is a registered trademark of the OPC Foundation.
- PROFIBUS® is a registered trademark of the PROFIBUS Nutzerorganisation e.V. (PNO).

- PROFINET® is a registered trademark of the PROFIBUS Nutzerorganisation e.V. (PNO).
- QR Code is a registered trademark of DENSO WAVE INCORPORATED.
- Subversion® is a trademark of the Apache Software Foundation.
- Windows® is a registered trademark of Microsoft Corporation.

List of Figures

Figure 1	View	12
Figure 2	Indicators – Display	13
Figure 3	Indicators – LEDs	13
Figure 4	Controls	14
Figure 5	Connections	15
Figure 6	Dimensional Drawings	16
Figure 7	Schematic Circuit Diagram	17
Figure 8	Product Menu Structure	21
Figure 9	SP1/rP1 – Switching Point/Reverse Switching Point for OUT1 – Hysteresis Functions	22
Figure 10	FH1/FL1 – Upper/Lower Switching Limiting Values for Window Function for OUT1	23
Figure 11	C.ASP = min. value; C.AEP = max. value	25
Figure 12	C.ASP = max. value; C.AEP = min. value	25
Figure 13	C.ASP/C.AEP – Example with Scaled Display Value	26
Figure 14	Hysteresis function with [r1ou]	26
Figure 15	Hysteresis function with [G1ou]	27
Figure 16	Window function with [r1ou]	27
Figure 17	Window function with [G1ou]	27
Figure 18	[r-cF] Function	28
Figure 19	[G-cF] Function	28
Figure 20	Input Process Data	42
Figure 21	Display – Analog Value Representation	43
Figure 22	Connection Example without IO-Link Master	45
Figure 23	Connection Example with IO-Link Master	46
Figure 24	Mounting Clip (Secured with an M4 Screw or Cable Tie)	47
Figure 25	Mounting Clip with Product Attached	47
Figure 26	Pushing a Button	53

List of Tables

Table 1	Legend for Figure “View”	12
Table 2	Legend for Figure “Indicators – Display”	13
Table 3	Legend for Figure “Indicators – LEDs”	13
Table 4	Legend for Figure “Controls”	14
Table 5	Legend for Figure “Connections”	15
Table 6	IO-Link Side/Evaluation Side (M12 A Plug)	15
Table 7	Sensor Side (M12 A Socket).....	15
Table 8	Legend for Figure “Schematic Circuit Diagram”	17
Table 9	Technical Data – Communication	18
Table 10	Legend for Figure “Product Menu Structure”	21
Table 11	Legend for Figure “SP1/rP1 – Switching Point/Reverse Switching Point for OUT1 – Hysteresis Functions”	22
Table 12	Legend for Figure “FH1/FL1 – Upper/Lower Switching Limiting Values for Window Function for OUT1”	23
Table 13	A.trm – Analog Termination for OUT2	24
Table 14	ou1 – Output Function for OUT1.....	24
Table 15	dS1/dr1 – Switching Delay/Reverse Switching Delay for OUT1	24
Table 16	ScAL – Displayed Value Scaling.....	24
Table 17	Example Menu Setting for Figure “C.ASP/C.AEP – Example with Scaled Display Value”	26
Table 18	coLr – Display Colors and Color Change.....	26
Table 19	diS – Displayed Value Update Rate.....	28
Table 20	Lo/Hi – Lower/Upper Input Measured Values	29
Table 21	dAP – Damping.....	29
Table 22	Variables – Default Command – General	29
Table 23	Variables – Default Command	30
Table 24	Variables – Product Access Blocks – General.....	30
Table 25	Variables – Product Access Blocks	30
Table 26	Variables – Manufacturer Name – General	30
Table 27	Variables – Manufacturer Name	31
Table 28	Variables – Manufacturer Text – General	31
Table 29	Variables – Manufacturer Text.....	31
Table 30	Variables – Product Name – General	31
Table 31	Variables – Product Name	31
Table 32	Variables – Product ID – General	31
Table 33	Variables – Product ID.....	31
Table 34	Variables – Product Text – General.....	32
Table 35	Variables – Product Text.....	32

Table 36	Variables – Serial Number – General	32
Table 37	Variables – Serial Number	32
Table 38	Variables – Hardware Version – General	32
Table 39	Variables – Hardware Version	32
Table 40	Variables – Firmware Version – General	32
Table 41	Variables – Firmware Version	33
Table 42	Variables – Application-Specific Attribute – General	33
Table 43	Variables – Application-Specific Attribute	33
Table 44	Variables – dAP – General	33
Table 45	Variables – dAP	33
Table 46	Variables – BitCoded_ActiveEvents – General.....	33
Table 47	Variables – BitCoded_ActiveEvents	34
Table 48	Variables – ParaConfigFaultCollection – General	34
Table 49	Variables – ParaConfigFaultCollection	34
Table 50	Variables – Loc – General	34
Table 51	Variables – Loc	35
Table 52	Variables – diS – General	35
Table 53	Variables – diS	35
Table 54	Variables – coLr – General	35
Table 55	Variables – coLr	35
Table 56	Variables – cFL – General	36
Table 57	Variables – cFL	36
Table 58	Variables – cFH – General.....	36
Table 59	Variables – cFH	37
Table 60	Variables – Hi – General.....	37
Table 61	Variables – Hi.....	37
Table 62	Variables – Lo – General	37
Table 63	Variables – Lo	37
Table 64	Variables – ou1 – General	38
Table 65	Variables – ou1	38
Table 66	Variables – dS1 – General.....	38
Table 67	Variables – dS1.....	38
Table 68	Variables – dS1 – General.....	38
Table 69	Variables – dS1.....	38
Table 70	Variables – SP_FH1 – General.....	39
Table 71	Variables – SP_FH1	39
Table 72	Variables – rP_FL1 – General	39
Table 73	Variables – rP_FL1	39

Table 74	Variables – ScAL – General.....	39
Table 75	Variables – ScAL	40
Table 76	Variables – A.Trm – General	40
Table 77	Variables – A.Trm	40
Table 78	Variables – C.ASP – General	40
Table 79	Variables – C.ASP	41
Table 80	Variables – C.AEP – General	41
Table 81	Variables – C.AEP	41
Table 82	Variables – C.uni – General.....	41
Table 83	Variables – C.uni.....	42
Table 84	Input Process Data	42
Table 85	Legend for Figure “Display – Analog Value Representation”.....	43
Table 86	Protecting the Power Supply.....	44
Table 87	Legend for Figure “Connection Example without IO-Link Master”.....	45
Table 88	Legend for Figure “Connection Example with IO-Link Master”.....	46
Table 89	Diagnostics via Indicators – LEDs	55
Table 90	Diagnostics via Indicators – Display	55
Table 91	Variables – Diagnostics – General.....	55
Table 92	Variables – Diagnostics	55
Table 93	Variables – Detailed Diagnostics – General	56
Table 94	Variables – Detailed Diagnostics	56
Table 95	Process Image – Error Types	56
Table 96	Process Image – Events	56
Table 97	Factory Settings	59
Table 98	Accessories.....	60

WAGO GmbH & Co. KG

Postfach 2880 · D - 32385 Minden
Hansastraße 27 · D - 32423 Minden

✉ info@wago.com

🌐 www.wago.com

Headquarters	+49 571/887 – 0
Sales	+49 (0) 571/887 – 44 222
Order Service	+49 (0) 571/887 – 44 333
Fax	+49 571/887 – 844169

WAGO is a registered trademark of WAGO Verwaltungsgesellschaft mbH.

Copyright – WAGO GmbH & Co. KG – All rights reserved. The content and structure of the WAGO websites, catalogs, videos and other WAGO media are subject to copyright. Distribution or modification of the contents of these pages and videos is prohibited. Furthermore, the content may neither be copied nor made available to third parties for commercial purposes. Also subject to copyright are the images and videos that were made available to WAGO GmbH & Co. KG by third parties.