smart-house Smoke Detector Type BSG-SMOx-U





- Smoke detector using Tyndall effect
- Detection of smouldering fires and flaming fires with smoke development
- Without radioactive sources
- Detection of areas up to 60 m²
- Transmission of alarms and Alive signals via Dupline®
- Operating voltage supplied by Dupline® bus
- Optional use of the smoke detector as alarm device for other detections such as gas, water and burglary via Dupline[®]
- Battery backup if the Dupline[®] connection is interrupted
- Acoustic alarm > 85 dB
- Constant monitoring of sensor sensitivity via Dupline®
- · For ceiling mounting

Product Description

BSG-SMOx-U is a detector for home/building applications which transmits the alarm event to the smarthouse controller. It is part of the smart-house concept and it can be used in all the functions where alarm signals are needed.

Ordering Key	BSGSMOAU
Decentral — Smoke Detector — No battery back-up — Smart Dupline®	

Type Selection

Battery back-up	Supply by Dupline®	
YES	BSG-SMO-U	
NO	BSG-SMOA-U	

Input Specifications

Detector	Optical (Tyndall effect)		
Response level	According to EN 12239 (95)		

Dupline® Output Specifications

Voltage	8.2 V
Maximum Dupline® voltage	10 V
Minimum Dupline® voltage	5.5 V
Maximum Dupline® current When the alarm is active	10 mA

Supply Specifications

Power supply	Supplied by Dupline®	
Current consumption typ.	2.5 mA	
Battery current consumption	20 μA, BSG-SMO-U only	
Supply voltage	9 VDC, BSG-SMO-U only	



General Specifications

Address assignments / channel programming	If it is used with the SH2WEB24 the address assignment is automatic: the controller recognises the module through the SIN	Indication	Red LED. Short flash once every 42 sec. (alive signal): the smoke detector is OK. Short flash every 0.5 sec.: Alarm.
	(Specific Identification Number) that has to be inserted in the SH tool. If it is used with the BH8-CTRLX-230, the channels have to be programmed by	BSG-SMO-U only	Red flash (42 sec.) and asynchronous beep = Dirty Red flash (42 sec.) and simultaneous beep = Low battery voltage.
Channel assignment I/O number 1	the BGP-COD-BAT Alarm signal.	Environment Degree of protection Operating temperature Storage temperature	IP 43 0° to +50°C -5° to +85°C
, o namber i	The status of the signal can	Meets the requirements of	ISO 12239
I/O number 2	be programmed (see below). Monitoring of sensor (tamper/presence). The sig- nal is always active if OK,	Connection Screwless detachable D+ D-	0.2 to 1.5 mm ² Signal GND
I/O number 3	otherwise inactive. Monitoring of battery voltage. The signal is active if the voltage is low.	Housing Dimensions Material Colour	For installation on ceilings Ø 100 x 54 mm ABS White
Only BSG-SMO-U	Only BSG-SMO-U	Weight	160 g
I/O number 4 Monitoring of sensor sensitivity.	Sound level	> 85 dB(A) / 3 m (10 ft)	
	The signal is active if the sensor becomes dirty.	Battery	IEC 6LR 61
I/O number 5 Forced alarm.		Average life, battery	2 years
	The smoke sensor can be	Alarm signalling	Acoustic and optical
	used as an alarm device for e.g. water, gas and burglar	Vds approval	G202055
	alarms.	CE Marking	Yes
Fail-Safe mode BSG-SMO-U BSG-SMOA-U	If the Dupline® connection is interrupted, the smoke sensor will still work, but as a normal individual smoke detector. If the Dupline® connection is interrupted, the smoke sensor will also be interrupted.	EMC Immunity - Electrostatic discharge - Radiated radiofrequency - Burst immunity - Surge - Conducted radio frequency - Power frequency magnetic fields - Voltage dips, variations, interruptions Emission - Conducted and radiated emissions	EN 61000-6-2 EN 61000-4-2 EN 61000-4-3 EN 61000-4-4 EN 61000-4-5 EN 61000-4-6 EN 61000-4-11 EN 61000-6-3 CISPR 22 (EN55022), cl. B
		Conducted emissionsRadiated emissions	CISPR 16-2-1 (EN55016-2-1) CISPR 16-2-3 (EN55016-2-3)

Mode of Operation

BSG-SMOx-U connected to the SH2WEB24 Coding/Addressing

If the device module is connected to the SH2WEB24 controller, no addressing is needed since the module is provided with a specific identification number (SIN): the user has only to insert the SIN in

the SH tool when creating the system configuration.

Used channels: 1 input channel, 4 output channels.

BSG-SMOx-U connected to BH8-CTRLX-230 Coding/Addressing

If the input module is connected to the BH8-CTRLX-

230 controller, the user has to program the channels using the BGP-COD-BAT: this module has:

- 4 output channels (I/O 1-4)
- 1 input channel (I/O 5) CH1 is pre-programmed on N1, CH5 on N2.

The alarm signal on CH1 can be programmed to be active

when the alarm is ON or when the alarm is OFF.

Fail/safe bit = 0 Signal active when the alarm is ON.

Fail/safe bit = 1 Signal active when the alarm is not active.



Mode of Operation

Mounting

To achieve minimum protection, one BSG-SMOx-U should be installed in front of each sleeping area or each floor. Higher protection will be achieved if one smoke detector is present in every room (except for the kitchen and the bath - here, false alarms may occur due to steam development). When using the BSG-

SMOX-u, the following issues must be observed:

• Rooms may have a floor area of up to 60 m² and a

height of up to 6 m

- Hallways and narrow corridors may have a width of up to 3 m (10 ft) and a length of up to 15 m (50 ft)
- The mounting location must be as close as possible to the centre of the room
- A minimum distance of 0.5 m (1.5 ft) must be maintained from walls and furniture

The BSG-SMO-U must NOT be mounted in the following locations:

- Near ventilation ducts or strong draughts
- Directly in the apex of

pitched roofs (a minimum distance of 30 cm (1 ft) from the apex must be maintained)


• In rooms which are usually very steam-, dust- or smoke-filled (for example in workshops, bathrooms and laundry rooms)

Connection of multiple smoke alarms

It is possible to interconnect several smoke alarms so that the alarm signalfrom one alarm is transmitted to all other connected alarms. The smoke alarms are connected in parallel using a 2-wire cable.

Note: Make sure that the total power consumption does not exceed the Dupline® controller's output when interconnecting the smoke alarms. Use a back-up battery to avoid voltage drop in the Dupline® bus when using interconnection.

Wiring Layout and Description



BSG-SMOx-U

Info: Please, when installing the smoke alarm (changing the battery), pay attention to the following:

- Make sure that the PCB is connected correctly to the multiple plug and that the two pole connector is connected to the PCB.
- Test the smoke alarm (by pushing the test button) when it has been placed in its retaining ring on the ceiling.

Dimensions

